




## Spare Parts List for JUNG Hydraulic Jacks

for Models:  
JHS 3, JHS 5 and JHS 10



	Designation	Part No.		
		JHS 3	JHS 5	JHS 10
①	Housing assy.	H 3 02 000	H 5 12 000	H 11 02 000
②	Piston assy.	H 3 04 001	H 5 14 001	H 11 04 001
③	O-ring	97 070 024-E	97 070 030-E	97 070 044-E
④	Lip ring	96 060 028-E	96 060 035-E	96 060 050-E
⑤	Circlips	Si 02 016	Si 02 025	Si 02 030
⑥	Hydraulic nipple	94 040 002-E		
⑦	Screw	94 040 001-E		
⑧	Guiding nut	H 4 04 040	H 5 04 043	H 11 04 043
⑨	Slide assy.	H 3 03 000	H 5 13 000	H 11 03 000
⑩	Screw	Sm 03 001		
⑪	Grease nipple	No 05 040		
⑫	Tape		No 05 059	No 05 061
	Seal Kit	Seal Kit JHS 3	Seal Kit JHS 5	Seal Kit JHS 10

